




FIG. 1B













FIG. 1F

FUJIBAYASHI Page 7 of 28 HITC.0004 10/802,003 REPLACEMENT SHEET







FIG. 2B



F/G. 2C




FIG. 3




FIG. 4A






FIG. 4B

					SN			∢			
60002	LIVE	%09	3000	1000	150	45	15	NW M	333	ш	ENABLE
									504		
514	513	512	510 511 512	510	509	207	909	202	Q		
STORAGE	STATUS		ACTIVITY 508	ACTIVI'	,	THRESHOLD	INTERVAL	HOST	VOLUME		503

F/G. 5

500













FIG. 7B














FIG. 10




FIG. 11




FIG. 12





FIG. 13






FIG. 15




FIG. 16